

## Club Warehouse Sizing Chart

Measure PIP circumference, the PIP joint is the first joint of the finger and is located between the first two bones of the finger.

| Product Code | Size | PIP circumference |
|--------------|------|-------------------|
| A99760       | XS   | 3.8cm             |
| A99761       | S    | 4.4cm             |
| A99762       | M    | 5.1cm             |
| A99763       | L    | 5.7cm             |
| A99764       | XL   | 7.0cm             |