

Club Warehouse Sizing Chart

For a proper fit of your RecoveryAir compression boots, measure the outseam of your leg from your ankle to hip flexor. Use this outseam length to select your size from the chart below. If you are in-between sizes, we recommend sizing **down** to ensure the best fit.


How to measure:

Outseam-

Measure from your ankle to your hip flexor, as shown here.

Width-

Measure the circumference (total distance around) of the thickest part of your thigh.



Product Code	Size	Max Width	Height
RA02091-01	Small	Up to 70cm	152 – 169 cm
RA02095-01	Medium	Up to 80cm	170 – 183 cm
RA02099-01	Large	Up to 81cm	183 – 198 cm